

# Track recording panel and widget



Track recording in Locus Map can be controlled by two kinds of Locus screen panel and a widget (available only in Locus Map Pro). The type of the track recording panel that can be selected in track recording settings - **sliding side panel**, which is set as default, and **compact bottom panel**.

## Sliding side panel

It slides from the left side of the screen and can be slid back by a finger. In case track recording is launched from a dedicated button in the function panel it can be slid by the "back" HW button. Its content is different in two phases of its use:

### Tracks recording start

Here you can select your recording profile, pre-set training scheme or external sensors. **track recording**.



obrazek track recording start panelu



The track recording can be started with countdown that can be defined in track recording settings

Ongoing track recording is also indicated by a tab on the left edge of the screen:

zalozka

### Track recording control&monitoring

Major part of the panel is covered by the track parameters that are actively monitored and displayed

during the recording.

#### obrazek track recording ctrl panelu

You can set which values you want to monitor:

- 1. go to settings > track recording > number of track monitoring items. Number of track monitoring items on the panel can be set from 4 to 12.
- 2. go back to the recording panel and long-tap the field you want to change
- 3. select from a vast range of available parameters obrazek vyberu sledovanych fci
- it is possible to define also two charts obrazek\_vyberu\_grafu



During the recording the elevation gain value can look confusing as it displays quite large numbers - however, the value is true and displays total of elevation gain measured by your device. As the GPS-measured altitude values are quite fuzzy, the result has to be optimized. The optimization is calculated later after saving the track so as not to waste battery life of your device.

Controls of the track recording are under the monitoring items:

Stops recording and proceeds to saving the track

pauses recording. Paused recording is also indicated by a on-screen label: obr\_paused\_onscreen

Repeated tapping unpauses the recording.

adds a waypoint to the track - you can select among a simple point, photo point, audio point and video point.

vyber\_bodu




#### **Options**

Options can be found in the topbar.

- More about track switches to the track detail screen
- **Save actual part** saves already recorded part of track individually without stopping recording just enter name, select folder, describe the track if you like
- Bluetooth manager switches to the bluetooth sensor management
- ANT+ manager switches to the ANT+ sensor management


https://docs.locusmap.eu/ Printed on 2025/06/15 21:36

- **Settings** switches to the track recording settings
- User guide offers help in User guide



## **Compact bottom panel**

An additional compact bottom panel is another option of displaying track recording. It can be set in track recording settings.



After track recording start, controls change into following:

bottom ctrl after start

Insert waypoint menu:

insert\_waypoint\_menu


Options menu:

options\_menu

**Settings** icon indicates used recording profile.

### **Track Recording Widget**

Widget is available only in Locus Map Pro




Track recording in Locus Map can be comfortably started from a widget. There are two sizes available:

https://docs.locusmap.eu/ Printed on 2025/06/15 21:36

#### **Small widget**

- track recording start button
- ullet track recording pause button ullet and stop button ullet visible when the recording is on
- recorded track distance indicator
- Locus Map app launch button



#### Large widget

Contains all controls of the small widget plus:

- recorded track time indicator
- insert point button
- $m{\hbar}$  track recording settings button icon indicates used recording profile

From

https://docs.locusmap.eu/ - Locus Map Classic - knowledge base

Permanent link:

https://docs.locusmap.eu/doku.php?id=manual:user\_guide:tracks:recording:panel&rev=147972731

Last update: 2016/11/21 11:21

